


OFFROAM

Do not mount accessories in front of or near the path of airbag deployment.
Check vehicle compatibility before install to avoid damage to vehicle mount point.
Designed to work with OEM doshboard only, not compatible with aftermorker modifications.
Do not mount heavy devices and/or use with flore, actession arms. Check the rated weight limit.

Noart electronics away from air flow to prevent heat damage.

Self-installation instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical ability required to properly perform an installation. Offfoons shall have no liability for damage or injury resulting from the installation or use of ny Offrom or high party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to a allow a vehicle to be operated safety and without distruction. Offrom product warranties do not

cover the installation, removal or re-installation of any product.



Mounting Base
Installation Instructions
Jeep Wrangler & Jeep Gladiator 2024