

COMPONENTS




Remove rubber insert on either driver or passenger side of the upper dash tray. Mounting base mounts to the threaded holes closest to the dash center.



Hook the front of the mounting base around the dash lip (01). Align it with the holes closest to the dash center as shown (02).


C-1







Fits driver or passenger side upper dash tray area. Optional: reinstall rubber inserts into upper dash tray.











WARNINGS

Da not mount accessories in front of or near the path of airbag deployment.
Chock whick compatibility between issal to aviad damage to whick mount point.
Dealinged to via/w DCH dobbagad and, not compatible which demovals modifications.
Do not mount heavy devices and/or use while harge detainin arms. Check the roted weight limit.
Heart effections are yritron of infort persent heat damage.

Self-institution instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical bility required to properly perform an installation. Offroan, shall have no lobility for damage or injury resulting from the installation are use of any Offroam or third party products. It is your responsibility to ensure that all products are installation in advence with localitys and engulations and in such a manner as to allow a vehicle to be operated safely and without distraction. Offroam product warranties do not cover the installation, removal or re-installation any product.

