



WARNINGS

- Do not mount accessories in front of or near the path of airbag deployment.
- Check vehicle compatibility before install to avoid damage to the vehicle mount point.
- Designed to work with OEM dashboard only, not compatible with aftermarket modifications.
- Do not use with 3rd party extension arms. Adhere to our phone weight limits.
- Mount electronics away from airflow to prevent heat damage.


Self-installation instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical ability required to properly perform an installation. Offroad shall have no liability for damage or injury resulting from the installation or use of any Offroad or third party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to allow a vehicle to be operated safely and without distraction. Offroad product warranties do not cover the installation, removal or re-installation of any product.



Mounting Base



L-key




Mounting Base Installation

Toyota 4Runner 2003-2009

01

Using the L-key provided, slightly loosen the screws to ensure the inner plate moves.


Do not fully remove the screws - keep about one thread engaged.



02

Insert the rear tabs of the mounting base into the corner vertical and horizontal gap in the air vent bezel as shown.


Press upward and outward on the mounting base into the corner of the air vent bezel.



03


Keep upward and outward pressure on the mounting base with the opposite hand.

Alternate tightening screws until mounting base has a snug fit.



POSITIONING

Fits in the positions shown.



WATCH THIS INSTALL

